

SnowQuik™ 1.3 Series

LIQUID CO₂ SNOW GENERATORS

KEY BENEFITS

- Simple, Compact, Versatile, Rugged, Economical snowmaker that generates approximately 300+ g of snow in 1 minute for ISBT / CGA specified tests.
- C-Model is specifically designed for hands-free use in CGA or ISBT methods for non-volatile residue (NVR), non-volatile organic residue (NVOR) & sensory tests from Liquid CO₂.
- 6 ft. (3 m) x 1/4 inch stainless steel braided, flexible PTFE lined transfer line with 1900 psig (13,100 kPag) pressure relief device for operational convenience and safety.
- Full flow high pressure / low temperature quick connect fittings allow for **tool-free** source connections.

MODELS

- **SnowQuik-1.3B**
Hand held snow generator with quick connect pressure relief assembly for easy, convenient storage tank, tank truck, rail car, or minibulk tank sampling.
- **SnowQuik-1.3C**
Trigger Clamp with quick connect pressure relief assembly inlet fitting for safe *Hands-Free* snow sample generation from storage tanks, tank trucks, or minibulk tanks.

SnowQuik-1.3B



Female QC
w/ dust plug
(QCF Dust Plug)



Fiberless, Synthetic
Snowbag
(Snowbag White)

SnowQuik-1.3C



RECOMMENDED ACCESSORIES



Digital Scale
(DS-2KG)



1L Polished NVR Can
(NVR 1.0L)



Cryo-Safety Gloves
(CRYGLV-14L)



ISO / IEC 17025:2005 Accredited Laboratory

AIRBORNE LABS INTERNATIONAL, INC
22C World's Fair Drive, Somerset, New Jersey 08873
T: (+1) 732-302-1950 F: (+1) 732-302-3035
E: Sales@AirborneLabs.com www.AirborneLabs.com